





USER MANUAL

www.newdirectiontackle.co.uk



ND TACKLE

Email: info@newdirectiontackle.co.uk



WEE/AX4045YF

Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately.

The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort, you contribute to recycle valuable raw materials and the treatment of toxic substances.

SMART CARBON SCADLE-C9



UK

SMART CARBON SCADLE-C9

The world is changing fast when it comes to technology. We at NEW DIRECTION TACKLE are keeping pace and are strongly committed to always find the best solution to improve your fishing experience.

On every fishing trip we always carry a lot of equipment. We thought why not combine the cradle and the scales and so we designed the Smart Carbon Scadle. This amazing new product helps you to reduce the amount of equipment and at the same time offers ultimate safety for the fish.

The Smart Scadle Project Team was established in 2018. Our three engineers and two senior testers took two years, and many field tests. Now we finally launch the amazing SMART CARBON SCADLE-C9.

Thanks to ND Tackle Team and Thanks to all our ND Tackle Followers.

Specifications

Scadle Dimensions: H 40 cm * W 69 cm * L 120 cm

Package Dimensions: H 16 cm * W 45 cm * L 72 cm

Weights: 4.5 kgs Batteries: Li-Ion 500 mAh, 3.7 V

Radio frequency: 2.4 GHz

Range: 10 m +/- (dependant on weather and environmental conditions)

SOLID FRAMEWORK

We developed a double-layer frame for our Smart Carbon Scadle, which greatly improves the accuracy of weighing.

The accuracy is now within 100 grammes.

Weighing range: 100 g to 50 kgs.

SMALLER & LIGHTER

The Smart Carbon Cradle unfolds at a size of 120*69*40 cm.

The folded size is only 70*40*15 cm.

By using carbon for the frame, the total weight is only 3.8kgs (including the bag).

WIRELESS RECEIVER

The wireless receiver displays the weight in LB / KG and the battery status of the Smart Carbon Scadle.


Thanks to a very low power consumption the Smart Carbon Scadle continuously works for more than 7 days on a single charge.



ND Tackle website

OVERVIEW

Smart Carbon Scadle



Scales Module

LED INDICATOR: POWER ON/OFF & RGBY

COVER

USB (inside)

Receiver

USB PORT

LED

DISPLAY

POWER ON/OFF


RESET WEIGHT / TARE

MEASUREMENT UNIT


REGISTER MODE

QUICK USER GUIDE


1. Turn the receiver on by pressing  for 3 seconds.




2. Turn on all four scales modules by pressing the button on each of the scales modules until the LED lights up.



3. Each channel (R, G, B and Y) on the receiver will change from 'OFF' to battery icon .



4. When all four scales modules are turned on and are connected to the receiver, the receiver will display the weight. If the display does not show zero, you can reset the weight and tare the scale by pressing  for 5 seconds.



How to turn ON/OFF the Scales Modules and the Receiver

Turn on the scales modules:


1. Press the button on the scales module until the LED lights up.
2. The LED will switch colours during boot process (blue -> red -> green).
3. The LED will show the colour of the respective channel.

When the scales module is turned on, the LED will always light up in the colour of the respective channel. ("R" - red / "G" - green / "B" - blue / "Y" - yellow)



Turn off the scales modules:

1. Press the button on the scales module until the LED flashes, then release it.
2. The LED flashes twice to indicate that the scales module is turning off.



Turn on the Receiver:

1. Press the button  on the receiver.
2. When the display shows "ND Tackle" release the button.
3. The receiver is turned on.

Turn off the Receiver:


1. Press the button  on the receiver.
2. When the display shows "Power off" release the button.
3. The receiver is turned off.

How to charge the Scales Module and Receiver

You can use the Micro USB-B cable with any smart phone charger to charge the scales module and the receiver.



Charging the Receiver:

1. Open the lid of the USB interface on the top of the receiver.
2. Connect a Micro B USB cable to the receiver.
3. The Battery ICON will flash on the display to indicate that the receiver is being charged.



Charging the Scales Module:

1. Open the cover on the bottom of the scales module to access the USB interface.
2. Connect a Micro USB-B cable to the scales module.
3. The LED indicates the charging status of the scales module.
Green: fully charged
Red: charging




How to reset the Scales Module to factory settings

1. Turn on the scales module.
2. Press the button on the scales module for 10 seconds.
3. The green LED flashes.
4. Turn off the scales module.
5. The scales module has been reset to factory settings.


How to reset the Receiver to factory settings

1. Turn on the receiver.
2. Press the button  and  simultaneously.
3. The display will show "Clean all".
4. The receiver has been reset to factory settings.




How to pair the Scales Modules with the Receiver


1. Reset the scales module to factory settings as described on Page 5.
2. Reset the receiver to factory settings as described on Page 5.
3. Turn on the receiver and the four scales modules, one after the other.
4. Press the button  and  on the receiver simultaneously for approx. 10 seconds to activate "register mode".
5. The text "R: NC" will flash on the display of the receiver.



6. Press the button on one of the scales modules.
7. The LED on the scales module will change to the color of the channel and the display of the receiver will show the battery icon for the channel.
8. After successfully pairing one scales module, the next channel will flash on the display of the receiver. ("R" - red >> "G" - green >> "B" - blue >> "Y" - yellow)



9. Repeat steps 6 and 7 until all four scales modules are paired with the receiver.
10. After all four scales modules are paired with the receiver the display will show the weight.



How to reset the weight / tare the scale

1. Turn on all four scales modules and the receiver.
Make sure the scales modules are paired with the receiver.
2. Press the button  on the receiver for five seconds. The four scales modules will be calibrated. The display shows zero.



How to Wake up the Scadle system

The scadle system can work in low power mode. After 2 minutes of inactivity the system will automatically switch to low power mode.

Low power indicator:

1. The display on the receiver will turn off and the green LED on the receiver will flash slowly.
2. The LEDs on the scales modules will flash slowly.


How to wake up the Scadle system

To wake up the system from low power mode you can either

- Place a weight of >500g (>1.1LB) on the Smart Carbon Scadle or
- Press any button on the receiver or one of the scales modules.


How to change the units LB / KG

Press the button  on the receiver. The unit will change between LB and KG.



How to change the display information from total weight to battery information or weight of every scales module

To change the display information shortly press the button  on the receiver.



Low Power warning:

The red LED on the scales module will continuously flash. You also can find the battery status on the receiver.

SUPPORT



NewDirectiontackle.co.uk/support/

We are committed to provide you with the best possible products and services. In case your ND Tackle product might have a defect or you need help or guidance we are always there for you. Please don't hesitate to contact us via our support center system (QR-Code link below).

Please understand that you will need a valid Email address to submit a ticket to us. For your reference we provide complete archives and the history of your support requests.



Support Center System

TELL US WHAT YOU THINK...

Please help us to optimize our existing products and to design your favourite future products. We are always keen to receive your feedback. No matter if you want to tell us what you like about our products, or if you might have an idea of how to make our products even better.

We are happy to receive your Feedback!

New Direction Tackle Team: info@newdirectiontackle.co.uk
info@newdirectiontackle.de



NEW DIRECTION TACKLE LTD

EC Declaration of Conformity
EU - Radio Equipment Directive 2014/53/EU

Declare under our sole responsibility, that the products:
- Smart Carbon Scadle-C9

to which this declaration refers, is in conformity with all the applicable essential requirements of EU Directive 2014/53/EU and that the essential radio test suites have been carried out.

Reference standards used for presumption of conformity:

ETSI EN 301 489-1 V2.2.0 : 2017

ETSI EN 301 489-3 V2.1.1 : 2017

ETSI EN 300 220-2 V3.1.1 : 2017

ETSI EN 300 220-1 V3.1.1 : 2017

EN 62479 : 2010

EN 60905-1 : 2006 + A11 : 2009 + A1 : 2010 + A12 : 2011 + A2 : 2013

SIGNATURE: _____

Benjamin Ferger
Director of New Direction Tackle LTD
Date: 06.06.2020

We're just happy that you're happy. If you don't know how to express your newfound joy, We've got a few suggestions....



Tell your friends and family



WhatsApp

WHATSAPP GROUP

<https://goo.gl/gRpJuB>



Happy?



NEWSLETTER

newdirectiontackle.co.uk/newsletter/



@New Direction tackle UK
@New Direction Tackle Germany
@New direction tackle NL
@New Direction Tackle FR
@New Direction Tackle Italia
@ND Tackle Bait boat



Share Your experience by writing a review on Amazon or Ebay

DE

SMART CARBON SCADLE-C9

Die Welt verändert sich schnell, wenn es um Technologie geht. Wir von NEW DIRECTION TACKLE halten Schritt und sind fest entschlossen, immer die beste Lösung zu finden, um Ihr Angelerlebnis zu verbessern.

Beim Angeln haben wir immer eine ganze Menge Ausrüstung dabei. Unser Ziel war es durch geschickte Kombination von Wiegematte und Waage die benötigte Menge an Ausrüstung zu reduzieren und die Benutzung zu vereinfachen, während die Sicherheit für den Fisch zusätzlich erhöht wird.

Das Smart Scadle Projekt Team arbeitet seit 2018 an diesem Produkt. Unsere drei Ingenieure und zwei Senior Tester haben in dieser Zeit intensiv entwickelt und getestet. Nun bringen wir die ausgeklügelte Smart Carbon Scadle-C9 auf den Markt.

Vielen Dank an das ND Tackle Team und an alle ND Tackle Follower.

Spezifikationen

Produkt Abmessungen: H 40 cm * W 69 cm * L 120 cm

Verpackungsmaße: H 16 cm * W 45 cm * L 72 cm

Gewicht: 4,5 kg

Batterien: Li-Ion 500 mAh, 3,7 V

Radio-Frequenz: 2.4 GHz

Reichweite: 10 m +/- (abhängig von Wetterbedingungen und Umwelteinflüssen)

STABILER RAHMEN

Wir haben einen doppelten Rahmen für unsere Smart Carbon Scadle entwickelt, welcher die Genauigkeit beim Wiegen deutlich verbessert. Die Toleranz liegt nun bei nur 100 Gramm. Wiegebereich: von 100 g bis 50 kg.

KLEINER & LEICHTER

Die Smart Carbon Cradle hat aufgebaut eine Größe von 120*69*40 cm. Auseinandergebaut nur 70*40*15 cm. Durch den Einsatz von Carbon für den Rahmen liegt das Gesamtgewicht bei nur 3,8 kg (inklusive Tasche).

KABELLOSER EMPFÄNGER


Der drahtlose Empfänger zeigt das Gewicht in LB / kg und den Batteriestatus der Smart Carbon Scadle an. Danke eines sehr geringen Energieverbrauchs kann die Smart Carbon Scadle durchgehend für mehr als sieben Tage mit einer einzigen Batterieladung betrieben werden.



ND Tackle Webseite

ÜBERBLICK


Smart Carbon Scadle



Waage-Modul


LED-ANZEIGE: AN/AUS & RGBY

ABDECKUNG




USB ANSCHLUSS

Empfänger




SNHELL-ANLEITUNG


1. Schalten sie den Empfänger ein, indem sie 3 Sekunden lang drücken.




2. Schalten Sie alle vier Waage-Module ein, indem sie jeweils den Knopf auf dem Waage-Modul drücken, bis die LED-Anzeige aufleuchtet.



3. Die Anzeige für die Kanäle (R, G, B und Y) auf dem Empfänger ändert sich von "OFF" zur Anzeige des Batteriestatus .



4. Nachdem alle vier Waage-Module eingeschaltet und mit dem Empfänger verbunden sind, zeigt der Empfänger das Gewicht an. Falls im Display nicht "000.0" steht. Können sie die Waage durch drücken auf den Knopf auf null setzen.



Waage-Module und Empfänger EIN/AUS-schalten



Waage-Modul einschalten:

1. Halten sie die Taste auf dem Waage-Modul (ca. 5 Sek.) gedrückt, bis die LED aufleuchtet.
2. Die LED ändert die Farben, während das Gerät hochfährt (blau -> rot -> grün).
3. Danach zeigt die LED die Farbe des entsprechenden Kanals.

Wenn das Waage-Modul eingeschaltet ist, leuchtet die LED permanent in der Farbe des entsprechenden Kanals.
("R" - rot / "G" - grün / "B" - blau / "Y" - gelb)

Waage-Modul ausschalten:

1. Halten sie die Taste auf dem Waage-Modul (ca. 3 Sek.) gedrückt, bis die LED blinkt.
2. Die LED leuchtet zwei mal auf, um anzuzeigen, dass Waage-Modul nun ausschaltet.



Empfänger einschalten:

1. Drücken sie die tast  auf dem Empfänger.
2. Wenn auf dem Display "ND Tackle" erscheint, lassen sie die Taste los.
3. Der Empfänger ist nun eingeschaltet.

Empfänger ausschalten:


1. Drücken sie die tast  auf dem Empfänger.
2. Wenn auf dem Display "Power off" erscheint, lassen sie die Taste los.
3. Der Empfänger ist nun ausgeschaltet.

Waage-Module und Empfänger aufladen

Benutzen sie das mitgelieferte USB-B-Kabel mit jedem beliebigen Smart Phone Ladegerät, um den Empfänger und die Waage-Module zu laden.



Empfänger aufladen:

1. Öffnen sie die Abdeckung des USB-Anschlusses an der Oberseite des Empfängers.
2. Schliessen sei ein USB-B-Kabel an dem Empfänger an.
3. Das Batteriesymbol des Empfängers blinkt während des Ladevorgangs.



Waage-Modul aufladen:

1. Öffnen sie die Abdeckung am Boden des Waage-Moduls, um an den USB-Anschluss zu gelangen.
2. Schliessen sie ein USB-B-Kabel an.
3. Die LED zeigt wie folgt den Ladestatus an.
Grün : vollständig geladen
Rot: Ladevorgang läuft




Waagemodul auf Werkseinstellungen zurücksetzen


1. Schalten sie das Waage-Modul ein.
2. Halten Sie die Taste des Waage-Modul (ca. 10 Sek.) gedrückt.
3. Die LED blinkt grün.
4. Schalten sie das Waage-Modul aus.
5. Das Waage-Modul wurde auf die Werkseinstellungen zurückgesetzt.

Waage-Module mit dem Empfänger verbinden


1. Setzen sie die Waage-Module auf Werkseinstellungen zurück. (siehe Seite 5)
2. Setzen sie den Empfänger auf Werkseinstellungen zurück. (siehe Seite 5)
3. Schalten sie den Empfänger und die vier Waage-Module nacheinander ein.
4. Halten sie gleichzeitig die Tasten **R** und **M** für ca. 10 Sek. gedrückt.
5. Auf dem Display des Empfängers blinkt der Text "R:NC"



6. Drücken sie die Taste auf einem der Waage-Module
7. Die LED zeigt die Farbe des Kanals an und auf dem Empfänger wird für den Kanal das Batteriesymbol angezeigt.
8. Nach erfolgreicher Verbindung eines Waage-Moduls, blinkt der nächste Kanal auf der Anzeige des Empfängers.
("R" - rot > "G" - grün > "B" - blau > "Y" - gelb)




9. Wiederholen sie die Schritte 6 und 7 bis alle vier Waage-Module mit dem Empfänger verbunden sind.
10. Das Display des Empfängers zeigt das Gewicht an, nachdem alle vier Waage-Module mit dem Empfänger verbunden wurden.



Empfänger auf Werkseinstellungen zurücksetzen

1. Schalten sie den Empfänger ein.
2. Drücken sie gleichzeitig die Tasten **R** und **M**.
3. Das Display zeigt "Clean all" an.
4. Der Empfänger wurde auf die Werkseinstellungen zurückgesetzt.




Waage tarieren

1. Schalten sie alle vier Waage-Module und den Empfänger ein. Stellen sie sicher, dass alle Waage-Module mit dem Empfänger verbunden sind.
2. Drücken sie (ca. 5 Sek.) die Taste **(R)**. Die vier Waage-Module werden kalibriert. Danach zeigt das Display "000.0" an.



Gewichtseinheiten LB / KG umschalten

Drücken sie die Taste **(M)** auf dem Empfänger, um zwischen den Einheiten und kg und LB umzuschalten.



Ruhezustand des Scadle Systems beenden

Das Scadle System schaltet nach 2 Minuten Inaktivität in den Ruhemodus.

Ruhemodus Merkmale:

1. Das Display des Empfängers ist ausgeschaltet und die LED auf dem Empfänger blinkt langsam grün.
2. Die LEDs an den Waage-Modulen blinken ebenfalls langsam grün.


Ruhemodus beenden:

Um den Ruhemodus zu beenden können sie entweder

- ein Gewicht von >500 Gramm auf das Wiegebrett aufbringen oder
- eine beliebige Taste auf dem Empfänger, oder einem der Waage-Module betätigen.

Angezeigte Informationen im Display ändern

Um die auf dem Display angezeigte information von Gesamtgewicht zu Batterieinformation und Einzelgewichte der Waage-Module zu wechseln, drücken sie kurz auf



Niedriger Batteriestand:

An dem Waage-Modul leuchtet durchgehend eine rote LED, wenn die Batterie aufgeladen werden muss. Den jeweiligen Batteriestatus können sie zusätzlich auf dem Empfänger sehen.

SUPPORT



NewDirectiontackle.co.uk/support/

Wir sind stets bestrebt Ihnen die besten Produkte und den besten Kundenservice zu bieten. Falls Sie jedoch ein Problem mit einem unserer Produkte haben sollten, oder Hilfe und Erklärung benötigen, sind wir immer für Sie da. Wenden Sie sich gerne jederzeit an unseren Kundenservice.

Sie erreichen uns über das Support Center System.
(Link via untenstehenden QR-Code)

Sie benötigen eine gültige E-Mail-Adresse, um uns zu kontaktieren. Als Referenz stellen wir vollständige Archive und den Verlauf Ihrer Supportanfragen zur Verfügung.



Support Center System

SAGT UNS EURE MEINUNG...

Bitte helfen Sie uns unsere bestehenden Produkte zu verbessern und Ihre zukünftigen Lieblingsprodukte zu entwickeln. Wir sind immer daran interessiert euer Feedback zu erhalten. Unabhängig davon, ob ihr uns erzählen möchtet, was euch an unseren Produkten gefällt, oder ob ihr eine Idee habt, wie man unsere Produkte noch besser machen kann.

Wir freuen uns auf euer Feedback!

New Direction Tackle Team: info@newdirectiontackle.co.uk
info@newdirectiontackle.de



NEW DIRECTION TACKLE LTD

EC-Konformitätserklärung

RICHTLINIE 2014/53/EU über die Harmonisierung der Rechtsvorschriften der Mitgliedstaaten über die Bereitstellung von Funkanlagen auf dem Markt und zur Aufhebung der Richtlinie 1999/5/EG

New Direction Tackle Ltd erklärt hiermit in Eigenverantwortung, dass das Produkt:
- Smart Carbon Scadle-C9

auf das sich diese Erklärung bezieht, mit den folgenden relevanten Standards bzw. den entsprechenden Dokumenten der RICHTLINIE 2014/53/EU übereinstimmt und dass alle notwendigen Testungen durchgeführt wurden um dies sicherzustellen.

Referenzstandards der Konformitätsannahme:

ETSI EN 301 489-1 V2.2.0 : 2017

ETSI EN 301 489-3 V2.1.1 : 2017

ETSI EN 300 220-2 V3.1.1 : 2017

ETSI EN 300 220-1 V3.1.1 : 2017

EN 62479 : 2010

EN 60905-1 : 2006 + A11 : 2009 + A1 : 2010 + A12 : 2011 + A2 : 2013

UNTERSCHRIFT: _____

Benjamin Ferger

Director of New Direction Tackle LTD

Datum: 06.06.2020